


UGE600 - Wiring diagram.



	Ξ	Battery powered	(((Wireless communication
LEGEND	L, N	230V AC power supply		Pump
	-	Fuse	M	Valve actuator
	COM, NO, NC	Voltage free output	T	Temperature sensor
	S, S1, S2	Input terminals	?	3-speed 230V AC fan
	SL	230V AC voltage output	\otimes	Light bulb or other load
		Contact normally open	T30NC	Thermoelectric actuator
		Contact normally closed	(Time programmer
		NC/COM/NO switch		External normally open contact

3118

Voltage converter

Boiler - Boiler connection * - Boiler's contacts

for ON/OFF thermostat (according to the boiler's instructions)

•